Remote Trainer TR – 600M
User Manual

What's in the box:



Receiver Collar

Remote Transmitter

O-rings

Contact Point

Receiver Collar Test Light



USB Charger Cable/AC Charger Adapter

USB AC Adapter

Remote Transmitter Lanyard

OutstandingPet ®
Remote Trainer TR – 600M

Thank you for choosing the OutstandingPet Remote Trainer TR-600M!

With a 650 yard range and a fully waterproof Receiver Collar, the TR-600M is designed for active outdoor use and reliable indoor training. This unit is recommended for use with medium to large sized dogs. With this unit you will be able to apply consistent training responses to gradually adjust your dog's behavior. This remote trainer has been used in eliminating nuisance barking, curbing aggressive behavior to humans or other dogs, establishing territorial boundaries in your home, training dogs to walk by their owner's heels without a leash, or assist in potty-training. Whatever your training needs, indoors or outdoors, the TR-600M will begin working from day one.

We are confident you and your dog will be pleased with the results from your purchase. If you need any further assistance, please feel free to visit out website for technical support or warranty claims at: www.outstandingpet.com

Please read this manual carefully before using the product.

Features

- 650 Yard (600 Meter) Range
- 2.4G ISM digital Transmission
- Adaptive Frequency Hopping (AFH) technology
- Rechargeable and Waterproof Receiver Collar
- Remote Transmitter with LCD Display
- Active Connectivity & Battery Level Indicators on Unit
- 7 Progressive Levels of Correction
- 2 Modes of Correction (Vibration & Electrical Stimulation)
- 1 Year Limited Warranty

Table of Contents

Operating Guide……..3

1.) Charging the Receiver Collar……..4

2.) Turning On / Off the Receiver Collar……..4

3) Inserting Batteries into the Remote Transmitter……..5

4.) Turning On / Off the Remote Transmitter……..6

5.) Pairing the Receiver Collar and Remote Transmitter……..6

6.) Testing the Receiver Collar and Remote Transmitter Pairing…..7

7.) Adjusting the Collar Receiver……..8

8.) Operating the Remote Transmitter……..9

9.) Remote Transmitter Sleep Mode……..11

Remote Trainer Best Practices & Precautions……..11

OutstandingPet (1) Year Limited Warranty……..12

Operating Guide

1) Charging the Receiver Collar

1. Lift the rubber cover on the Receiver Collar.
2. Connect the USB Charger Cable into the USB AC Adapter.
3. Insert the USB Charger Cable connector into the Receiver Collar Charging Interface (*figure 1*) for 6 to 8 hours (on the first use of the product, charge the Receiver Collar for 12 to 14 hours).
4. While the Receiver Collar is charging it will have a solid red light.
5. When the Receiver Collar is fully charged, the red light will blink every four seconds; the red light will flash every one second if the Receiver Collar needs to be recharged.
6. When charging is complete, replace the rubber cover over the Receiver Collar Charging Interface.



figure 1 – Receiver Collar Charging Interface

Charging the Receiver Collar – Indicator Lights

Receiver Collar Indicator Light	Receiver Collar Status
Red light is solid in color	Receiver Collar is charging
Red light blinks every 4 seconds	Receiver Collar is charged
Red light blinks every second	Receiver Collar requires charging

2) Turning On / Off the Receiver Collar

1. Press the Power Switch (*figure 2*) for three seconds to turn on the Receiver Collar (the red light will go solid and begin to blink every four seconds if sufficiently charged)
2. While the Receiver Collar is on, press the Power Switch for three seconds to turn off the Receiver Collar (the red light will turn solid and then turn completely off)



figure 2 – Receiver Collar Power Switch and Charging Interface

Turning On / Off the Receiver Collar – Indicator Lights

Receiver Collar Indicator Light	Receiver Collar Status
Red light is off	Receiver Collar is turned off
Red light blinks every 4 seconds	Receiver Collar is turned on

3) Inserting Batteries into the Remote Transmitter

1. Remove the Battery Lid from the back of the Remote Transmitter
2. Insert three AAA batteries, in the Remote Transmitter, matching the (+)/(-) signs (*figure 3*).
3. Place the Battery lid back on to the Remote Transmitter.
4. You can monitor the battery level in the Remote Transmitter LCD Display, by checking the Battery Charge Indicator (*figure 7*).



figure 3 – Inserting Batteries into the Remote Transmitter

4) Turning On / Off the Remote Transmitter

1. Hold the ⏻ button for three seconds to power up the Remote Transmitter (the LCD will turn on to indicate a successful power-up).
2. While the Remote Transmitter is turned on, hold the ⏻ button for three seconds to power down the unit (the LCD will turn off to indicate the successful power down).

5) Pairing the Receiver Collar and Remote Transmitter

Note: This unit comes pre-paired; if you wish to connect an existing component with a new component, then proceed with the pairing process described below.

1. Power down the Remote Transmitter, by holding the ⏻ button for four seconds (Once the LCD is blank, confirm the Remote Transmitter is turned off by pressing the ⏻ button and make sure the Remote Transmitter is not in Sleep Mode).
2. Power down the Receiver Collar by holding down the Power Switch for four seconds (confirm the Receiver Collar Indicator Light is off).
3. While the Remote Transmitter is off, Hold the ⏻ button on the Remote Transmitter for ten seconds; it will first display the number "1" (which is the normal Power Up state) and then it will begin to blink "code" on the lower lerft of the Remote Transmitter LCD Display. Release the ⏻ button, when "code" is flashing.

4. While the Remote Transmitter is flashing "code" on the LCD, hold down the power switch on the Receiver Collar for 10 seconds. The Receiver Collar Indicator Light will turn on first as a solid light, then it will begin to blink rapidly (as it seeks to pair with the Remote Transmitter); when the Receiver Collar's Indicator Light begins to blink, release the Power Switch on the Receiver Collar (ensuring that the Remote Transmitter is still flashing "code").
5. The Remote Transmitter and Receiver Collar should pair within two to three seconds.
6. If the Receiver Collar and Remote Transmitter pair successfully, the Receiver Collar Indicator Light will blink four times and go solid. The Remote Transmitter LCD will no longer display "code" to indicate a successful pairing.
7. If the Receiver Collar and Remote Transmitter do not pair successfully, the Remote Transmitter LCD will display the number "8" and go back to the default Power Up status; please repeat steps 1 through 6, if you do not initially pair the units successfully.



figure 4 – Receiver Collar Test Light

6) Testing the Receiver Collar and Remote Transmitter Pairing

1. Place the Test Light on the Contacts Points of the Receiver Collar.
2. Press the the ⏻ button on the Remote Transmitter, the Test Light will turn on (*figure 5*).



figure 5 – Receiver Collar Test Light Turning On

7) Adjusting the Collar Receiver

1. Turn the Receiver Collar off.
2. Place the Receiver Collar on the dog and adjust the Receiver Collar Straps to ensure the contact points are centered underneath the dog's neck.
3. Pull any excess strap material through the Receiver Collar Loop.
4. For optimal results, ensure the Receiver Collar is snug on the dog's neck, but you should be able to insert one finger between the Receiver Collar and the dog's neck.

8) Operating the Remote Transmitter

figure 6 – Remote Transmitter

Increase Correction Level
Press the % button to increase the Correction Level. Each press of the % button increases the Correction Level by one step (out of seven total). The LCD will increase the corresponding level. If you hold the % button for more than three seconds, the Remote Transmitter can be powered-on or powered-off.

Decrease Correction Level
Press the − button to decrease the Correction Level. Each press of the − button decreases the Correction Level by one step (out of seven total). The LCD will display the corresponding level.

Electric Stimulation
Press the ⚡ button to send an Electric Stimulation to the Receiver Collar. When the Electric Stimulation is successfully sent, the Remote Transmitter will display on the LCD a number between 1 and 7 indicating the Correction Level applied and the Electric Stimulation symbol (*figure 7*). If the Electric Stimulation is not sent successfully, the Correction Level number and the Electric Stimulation Symbol will not display on the Remote Transmitter. If the ⚡ button is held down, an Electric Stimulation will be sent for five consecutive seconds, turn off for five seconds, and then be sent for another five consecutive seconds, continued indefinitely, until the user releases the button.

Vibration
Press the 〰 button to send a Vibration to the Receiver Collar. Each Vibration lasts for three seconds and will continue indefinitely. If the Vibration is sent successfully to the Receiver Collar, the Remote Transmitter LCD will display the Vibration Symbol (*figure 7*).

figure 7 – LCD Display Window on Remote Transmitter

9) Remote Transmitter Sleep Mode

If the Remote Transmitter and Receiver are not operated for a period of time, the Remote Transmitter will automatically go into Sleep Mode and turn of the LCD Display Window. If you press any button on the Remote Transmitter, it will power up to the normal "On" state.

Remote Trainer Best Practices & Precautions

1. Some dogs will require multiple trainings session to be comfortable with the Remote Trainer.
2. Under normal circumstances this product will work from 650 yards (600 meters); however, if there obstacles between the Remote Transmitter and Receiver Collar it may reduce the effective transmissions range of the Remote Trainer.
3. The Receiver Collar is completely waterproof and designed for active outdoor use; this product warranty covers water damage.
4. This product is intended for use on pets such as dogs. DO NOT use it on the human body in any way.
5. Never leave the Receiver Collar on your dog's neck for more than 12 hours every day.

OutstandingPet (1) Year Limited Warranty

WARRANTY COVERAGE

OutstandingPet's warranty obligations for this product are limited to the terms set forth below:

Sunfire Enterprises, LLC - OutstandingPet ("OutstandingPet") warrants this product against defects in materials and workmanship, when subject to normal and proper residential use, for a period of ONE (1) YEAR from the date of original retail purchase, If a defect exists, at its option OutstandingPet will (1) repair the product at no charge, using new or refurbished replacement parts, (2) exchange the defective product component with a replacement product component which has been manufactured from new or serviceable used parts and is at least functionally equivalent to the original product or defective component, or (3) refund the purchase price of the product. A replacement product/part assumes the remaining warranty of the original product or thirty (30) days from the date of replacement or repair, whichever provides longer coverage for you.

This warranty does not apply: (1) to consumable parts, such as batteries, unless damage has occurred due to a defect in materials and workmanship; (2) to cosmetic damage, including but not limited to scratches, dents, and broken plastic; (3) to damage caused by use with non-OutstandingPet products; (4) to damage caused by accident, abuse, misuse, flood, fire, earthquake or other external causes; or (5) to a product or part that has been modified to alter functionality or capability.

OutstandingPet will not be liable under this warranty for any defect, failure or malfunction of any of its products caused by normal wear, abuse, misuse, unauthorized adjustments or disassembling. OutstandingPet will not be liable for any consequential damages resulting from

any defect in material or workmanship of any of its products. Some states do not allow limitations on how long an implied warranty lasts or exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

Warranty is non-transferrable and shall automatically terminate if the original retail consumer purchaser resells the OutstandingPet product or transfers the property on which the OutstandingPet product is installed.

OBTAINING WARRANTY SERVICE

To obtain warranty service, you must follow OutstandingPet's warranty process. To begin the process, please send us an email at support@outstandingpet.com describing the nature of the problem in this email include your full name, email address, date of purchase, phone number, and where you purchased the product; otherwise, you may also call the OutstandingPet Customer Support group at 866-933-8429 to begin your claim. You will be responsible for all return shipping costs under this warranty.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: Modification or changes to this equipment not expressly approved by OutstandingPet may void the user's authority to operate the equipment.

Copyright 2012
OutstandingPet®

www.outstandingpet.com